

BENCINI CARRYING CASE for KOROLL II e KOROLL 2



Characteristics and functions

Hard plastic case in black, complete with soft plastic shoulder strap, non-adjustable about 95 centimeters long.

The bag can be split into two parts: the upper part can be easily separated from the lower one by rotating the two pins so as to free them from the slots in the back of the bag.

At the bottom of the bag, in the center, is the chrome screw that serves to hook the camera to the bag.

On top of the bag, at the rear there is formed a tab which, when raised allows to open the bag without separating the two parts.

On the lower part of the bag, at the back, there are two holes located in correspondence with the circular windows of the camera back in order to allow viewing of the numbering of the film during the 24 shots.

Weight: 112g.