## NIKON COOLPIX L12 (Digital Camera) 2007



Serial nr. 30365295

## **Characteristics and functions**

7.1 Megapixel digital camera with Nikon 3x optical zoom lens 5.7-17.1mm\* 1: 2.8-4.7 (\* comparable to35-105mm in 35mm format).

The Coolpix L12 is equipped with 21MB internal memory and can house Secure Digital (SD) cards. The card is inserted by opening the door located on the right side of the camera. By pressing the On / Off key, which is located in the center of the upper cover, the lens comes out and the camera is ready to shoot.

The back of the camera is almost entirely occupied by the 2.5 inch display with 115,000 pixel resolution.

Along the right edge of the back are arranged, from top to bottom, the pivoting button for the Wide / Tele function, the Menu button, the multi-function button / OK, the button to display the indications on the monitor, the button for the delete images

(trash can symbol), the cursor for setting the shooting functions (Scenes) and the LED of the 'Pronto Flash' indication.

The socket for the connection with the USB cable is located under a rubberized cover positioned above the SD card door, along the left side of the Coolpix L12. On the back we find the threaded hole for fixing to the stand, the serial number with the production indications (camera Made in China) and the door of the battery compartment. Along the left side, in an advanced position, there is a frame with a hole for attaching the wrist strap.

## **Technical Specifications**

Sensor:	CCD maximum resolution 7.1 Megapixel (Maximum: 3072x2304) Sensitivity: ISO 100, 200, 400, 800, 1600
Times:	From 1/1000" to 10"
Diaphragms:	f / 2.8-4.7 max-aperture (+ 2 / -2 diaphragms with division in 1/3)
Lens:	Nikon Optical 5.7-17.1mm - f.1:2.8-4.7
	Focusing system with autofocus from 50cm to infinity
	Possibility of manual focusing
	Shooting with 'Macro' function at a minimum distance of 15cm.
	4x digital zoom
Viewfinder:	Absent
Colors:	Chrome or black
Accessories:	Tripod mount, wrist strap attachment, built-in lens cover,
	self-timer. PC connection with USB 2.0
Power supply:	Two 1.5v AA batteries
Weight:	123g., batteries, SD card and strap excluded
Dimensions:	Length 3.58in., width 2.40in., thickness 1.02in.

