

MINOLTA ACCESSORY CLIP II 1960



Serial Nr.: no
Minolta Code: 6012-720

Characteristics and Functions

The Minolta Accessory Clip is the flash shoe to be applied to the Minolta Reflex cameras introduced starting from 1958. The Minolta Accessory Clip II can be adapted to the SR-1 and SR-3 models. It should be applied to the camera eyepiece by removing the black metal crown from the eyepiece itself, unscrewing it, then introducing the accessory and finally screwing the eyepiece crown back down.

Weight 16g. Dimensions: width 45mm.; length 39mm.; thickness 22mm.