

# MINOLTA ACCESSORY HOT SHOE for XM – XK – X-1



Serial Nr.: no  
Minolta Code: 6803

## Characteristics and Functions

The Minolta Accessory Hot Shoe, presented in 1973, is the hot shoe dedicated to the professional reflex camera presented by Minolta in the same year. The Hot Shoe must be applied astride the film recovery pawl using the special rails. To remove it from its position, when not in use, press the chrome release button located in the rear part of the left cap and move the Hot Shoe outwards until it is completely removed.

Weight 20g. Dimensions: width 25mm.; length 31mm.; height 28mm.