

MINOLTA CASE for HI-MATIC 7s (1966)



Serial Nr. no
Minolta Code: 6178-110

Characteristics and Functions

This case, made of black rigid leather, is the typical ready-to-bag made up of two separable parts. The camera is secured in the bag by means of the large chrome screw located under the bottom of the case. The separation and removal of the upper cap is allowed by the presence of an automatic and an asymmetrical ring located one above the other, on the back of the bag. At the center of the front protuberance is set a black metal plate where the chromed inscription "minolta" appears. The bag has a thin shoulder strap in black plastic printed with a leather effect, adjustable and hooked to two chromed metal loops placed on the sides of the lower part.

Weight 168g., Shoulder strap included Height 113mm. Width 160mm. Depth 98mm.