

MINOLTA CASE for Minolta 35 B (1947)



Serial Nr. No
Minolta Code: unknown

Characteristics and Functions

This case, made of hard brown leather, is the typical ready-to-bag made up of two separable parts. The camera is fixed to the bag by means of the large chrome screw located under the bottom of the case, on the far right. The separation and removal of the upper shell is allowed by the presence of two snaps placed on the bottom and one positioned in the center of the back of the bag. On the front protuberance "Minolta" is hot engraved, while on the back are engraved the symbol of Minolta used in those years formed by a prism inserted in a plano-convex lens that has the inscription "CHIYOKO" inside and, immediately below the wording "MADE IN OCCUPIED JAPAN". The bag has a thin and short leather shoulder strap, adjustable and removable that passes through four leather loops located on the sides and under the case. A very thin rectangle of leather is sewn inside the back that serves as a memo pocket.

Weight 155g., Shoulder strap included Height 90mm. Width 150mm. Depth 73mm.