

# MINOLTA DATA BACK G

## 1981

(New Logo)



Serial Nr. no  
Minolta Code: 8733-200

### Characteristics and Functions

The Minolta Data Back G can be used with the XG-2, XG-9 and XG-M cameras. You can set day, month and year or alpha-numeric codes. The programming of the years goes from 1979 to 1999 inclusive. By means of the three circular selectors the programming of date or code is set. The first on the left is used to set the day (1 > 31), the central one is used to set the month (1 > 12) or an alphanumeric code (A > G), the last is the one assigned to setting the year (1979 > 1999) or an alphanumeric code (A > I). The OFF - Color / B&W 32 - Color 400 / B&W selector allows you to calibrate the brightness of the engraved data according to the sensitivity of the film used or to turn off the Data Back G (OFF) thus avoiding the engraving of the negative during shooting. Operation is ensured by two 1.5v batteries (type 10L14 or similar to silver oxide). The batteries can be reached by turning the screw of the black door with the help of a coin. The sync cable must be inserted into the flash socket of the camera in order to allow synchronization at the time of shooting. Replacing the standard back with the Data Back G is very simple: simply open the back, move the small zipper lever down and remove the back from the upper ring. With the reverse operation, the Data Back G.

Weight 90g., Batteries excluded.

Dimensions: length 139.5mm .; height 53mm .; thickness 27mm.