MINOLTA FLASH SHOE ADAPTER FS-1100



Serial Nr. no Minolta Code 8825-670

Characteristics and Functions

The Minolta Flash Shoe Adapter FS-1100 allows you to use the accessories Flash AF 4000, AF 2800, AF 1800, Macro Flash AF 1200, OC cable, IR-1N infrared remote control and DR-1000 data receiver on Dynax 7000i and 3000i, the only two of the second generation of Minolta autofocus SLRs on the market at the time of the launch of the FS-1100. However, there are some limitations that do not allow some functions of the flash (see diagram).

The flashes of the "PX" and "X" series cannot be used with the Dynax 7000i and 3000i luminaires. Weight 17g. Width 27mm.; height 25mm.; depth 29mm.

ACCESSORI	USATO CON DYNAX 7000i	USATO CON DYNAX 3000i
FLASH AF 4000 / AF 2800 / AF 1800	 Quando il flash è acceso il lampo viene emesso ogni volta che si effettua una ripresa fotografica L'illuminatore agli infrarossi del flash non funziona (funzionerà solo quello incorporato nella Dynax 7000i) 	
Macro FLASH AF 1200	 Quando il flash è acceso il lampo viene emesso ogni volta che si effettua una ripresa fotografica 	
Comando a distanza IR-1N, ricevitore dati DR-1000	Utilizzabili senza nessuna restrizione	Non si possono uti- lizzare. La Dynax 3000i non ha l'at- tacco per il co- mando a distanza