

MINOLTA POCKET FLASH 25 1975



Serial Nr.: no
Minolta code: 8664-200

Characteristics and Functions

The Minolta Pocket Flash 25 is an electronic flash dedicated to Pocket Autopak 230, 250 and 270 cameras. It is attached to the left of the camera by means of a dedicated shoe; a small red button is used - by pressing it - to free the slide to separate the flash from the camera itself. This flash has a Guide Number 25 (in meters for 100 ISO film). The working range is from 7m to 1.2m. The dish is not adjustable and has a coverage angle equal to a focal length of 26mm. comparable to 35mm. approximately in the format 24x36mm. On the left side are the battery compartment door (2x1.5v AA batteries). It is not possible to use

Ni-Cd batteries. In the lower part, a table summarizes the distances (in meters and feet) for the correct use of the flash according to the type of film and the camera used. The On/Off switch and the red Ready-Flash light are located on the back of the Pocket Flash 25.

Weight 105g., Batteries excluded.

Dimensions: width 90mm.; height 26mm.; depth 58mm.



FILM TYPE	POCKET AUTOPAK	
	230 250	270
COLOR PRINT	1.2 - 3.5 m 4 - 11 ft	1.2 - 5.5 m 4 - 18 ft
COLOR SLIDE	1.2 - 2.5 m 4 - 8 ft	1.2 - 5 m 4 - 16 ft
BLACK & WHITE	1.5 - 5 m 5 - 16 ft	1.5 - 7 m 5 - 23 ft
MINOLTA CAMERA CO., LTD.		