

BOUNCE FLASH BRACKET #292



For use with Models 80, 80A, 80B, 110A, 110B, 120, 150, 160, 800, 850 and 900.

Allows for 90-degree bounce flash for both horizontal and vertical pictures and it preserves the 'Hot Shoe' feature of these cameras (hot shoe contact).

This bracket also preserves the camera's shoe sync contact, but the #292 is made of plastic, and has a simple L-shape.