


CUTTER BAR ADAPTER #274



For non-locking cutter bar.
To equip Polaroid Land Cameras (larger size).