


CUTTER BAR ADAPTER #274L



For locking cutter bar.
To equip Polaroid Land Cameras (larger size).