

# POLAROID Land Camera M20 SWINGER



<b>Year of construction :</b>	1965-1970
<b>Film type:</b>	Roll-film
<b>Shutter:</b>	Mechanical 1/200 second
<b>Meter:</b>	Exposure setting assisted via built-in photometer
<b>Diaphragm:</b>	-
<b>Times:</b>	Single speed: 1/200 second
<b>Lens:</b>	100mm f/17 (Meniscus, single plastic element)
<b>Synchronisation:</b>	Built in flashgun for AG-1 bulbs
<b>Self-timer:</b>	No
<b>Focusing:</b>	Fixed focus
<b>Characteristics:</b>	Rigid Black and white plastic body
<b>Accessories:</b>	Rubber wrist strap
<b>Note:</b>	Earlier production models have both "YES" and "NO" indications in the finder. Later ones have a plain checkerboard 'reference' screen on the photometer, thus indicating proper exposure with only the "YES" message.
<b>Estimated Production:</b>	Not completely determined