

# POLAROID Land Camera The Reporter



<b>Year of construction:</b>	1977
<b>Film type:</b>	107/87 (B/W) – 108/88 (Color)
<b>Shutter:</b>	Electronic - Aperture-priority automatic exposure only. (Shutter does not need re-cocking before next exposure)
<b>Meter:</b>	CdS
<b>Diaphragm:</b>	From f/9.2 to f/42 - Lens aperture at 3000 ASA is fixed at f/58.
<b>Times:</b>	From 10sec. to 1/500sec
<b>Lens:</b>	114mm f/9.2 - 3-elements (plastic)
<b>Synchronisation:</b>	Built-in flashcube socket for flash; no connector for other flashguns.
<b>Self-timer:</b>	No
<b>Focusing:</b>	Front-cell focusing, with distance scale on lens ring.
<b>Characteristics:</b>	Rigid, non-parallax corrected viewfinder; no rangefinder. Settings for film speeds of 80 and 3000 ASA (3000ER). Exposure compensation dial with range of -1/+2 stops ("Lighten/Darken" control).
<b>Accessories:</b>	Nylon carrying strap, tripod socket, cable release.
<b>Note:</b>	Film speed selector is on top of shutter housing. The Reporter can use either standard rectangular format or square format pack films. Viewfinder has masks for both film formats, but does not indicate which format is in use.
<b>Estimated Production:</b>	-