

# TRIPOD ADAPTER #261



This is a metal bracket which extends the tripod mount on the bed of the camera so that the tripod socket 'cleans' the focusing knob.

**Note:** For use with Polaroid Land Camera models 110, 110A, 110B, 120, 150, 160 and 800. There are two versions of boxes: the oldest has the word 'Polaroid' in the red field.