

FLASHGUN #268



For use with all 100- to 300- series folding pack cameras except the 360. This is the standard flashgun for folding pack cameras. Integrated hinged flash shield is tinted blue; clear M3 bulbs can be used with both B&W and color film.

Flash reflector swivels for bounce flash.

Spring-loaded lever clips flashgun to top of camera; cord plugs into PC socket on side of shutter housing.

Note: the battery (one 1.5v AA-size cell) is replaced by removing the two screws at the bottom of the case.